


## DESKTOP CONTROLLER SOFTWARE

Cable and radio versions.  
 PC interface.  
 Remote control.  
 Data Logging.  
 Compression or tension.  
 Single print to MS W.



**Control**

Tare Units Peak Hold On / Off

Scientific Display  Load Link Address: 10

Peak Hold **Off**

Units **kg**

**784.**

**Logging Options**

Display Only

To Excel Cell

Log To Excel

Which Cell: A1

Starting Cell: A1

Log Interval (s): 0

Started - Receiving Data

## SPECIFICATIONS

Simple, self-installing Windows based PC package that allows the operator full control and display of any Straightpoint products.  
 Will also log data directly into Microsoft Excel or Word.  
 Wire version is supplied with ten metres of cable.  
 Telemetry version supplied with USB transmitter.

### Part Number


### DCP/10M

### RDCP

For use with

LLP, MWP, LBP

Radio loadcells



**Straightpoint** (UK) Limited

World Leaders In Load Monitoring Technology

**Telemetry Load Link Controller Software** v2.00

**DATA CAPTURE**

Display Unit Selection: Load Link Force/Weight

**0 kg**

Peak Hold Facility: Off, Reset

Gross/Net Display Selection: Gross

Buttons: Wake Load Link, Sleep Load Link, Return to Set-Up Page, Data Logging Facility

